

User Manual for Muscle Massage Gun with LCD Touch Screen T-07



Specifications

- Input: AC 110V-240V
- Power: 24W
- RPM: 1800 - 3200 per min
- Battery: 2500mAh
- Working time: 2h+

Charging instructions

Fully charge the battery for up to six hours before the first use. To do so, connect the DC end of the included 24V adapter to the battery's charging port and plug the AC end into the wall outlet. The LED on the battery will start pulsating to show the battery level and indicate active charging. When fully charged, all LEDs will stop pulsating and will remain powered on.

The battery may be charged at any time and at any level. Please bear in mind that it's not recommended to fully deplete the battery to the red LED level.

The average run-time is over 2 hours, depending on speed level and pressure applied during usage.

Operating instructions

Power on the device by moving the power switch on the bottom of the battery to the ON position. Power it off by moving the power switch to the OFF position.

With the powered on, press the power button once to turn the device to level one. Press the + button to change levels up to level 20, and the - button to turn back levels up to level 1. Press the power button again to stop massaging.

With the massager turned off, insert the applicator by pressing it in. To remove it, simply pull it out. Massage the desired body part at the desired speed and applying the pressure as needed.

To remove the battery, press the battery release button on the side and firmly pull down the battery/handle. To put it back, align the release button with the hook on the battery and push the battery/handle back.

Maintenance, cleaning, and storage

- Use a slightly damp towel to clean the device and dry it with a soft cloth
- For storage or travel, remove the battery and store it in the supplied box.