



Digital Family Organizer with Touchscreen Display





1. Type-C
2. Power supply
3. Wall-mounting hole
4. Mounting hole
5. Wall-mounting hole
6. Bracket

Power Button

Hold the power button for about 5 seconds to power on the frame. When the frame is on, press the power button once to turn the screen on or off. Hold the power button for about 2 seconds to get the power off option. To avoid any possible damage to the frame, please do not unplug the power adapter from the frame while the device is on.

Before Device Installation

Wall-Mounting Tips

Take the height of all device users into consideration. It is recommended to install the device at an eye-level height. Ensure sufficient space for both horizontal and vertical mounting orientations.

Do not drill holes above wall studs, electrical wires, or pipes.

Before installation, unplug the device from the power socket and keep it away from water sources.

Required tools



Electric drill




Hammer



Wall protection tape

Other accessories inside the packaging box



Power adapter



Bracket



Two screws



Two expansion anchors

The included screws and expansion anchors are suitable for drywall, brick, concrete, or tile walls.

Download AiMOR app on your mobile phone

To share your schedule with compatible calendar devices worldwide, please first download the free AiMOR app on your mobile device.

Search for "AiMOR" in the App Store (iOS) or Google Play (Android) to download the AiMOR app.



Bind and Connect Devices

To synchronize your schedule with AiMOR Calendar, you need to connect the AiMOR app to the AiMOR Calendar device. Follow the steps below for connection:



Open the device's member management settings.

Open device sharing.

Enter the device code in the "AiMOR APP" to bind the device.

You can now synchronize your mobile phone with the calendar.



Click on the device sharing icon“ “on the AiMOR Calendar A pop-up will appear with a unique code, which is valid for 12 hours.

Now, open the AiMOR app on your phone, tap the " " icon under the device tab, enter the code from the AiMOR Calendar, and click. Your mobile app is now connected to the photo frame.

Share the AiMOR Calendar code with friends and family. They can add the AiMOR Calendar and start synchronizing or creating schedules, household chores, etc., to it. There is no limit to the number of mobile users connected to the AiMOR Calendar.


Introduction to Functions on Device Homepage

Main Functions on Homepage




1. Date
2. Time
3. Weather
4. Reminder
5. Member
6. Switch views
7. Back to today
8. Chore display
9. Add schedule


Notification



1. Content display
2. Ring reminder
3. Close pop-ups
4. Next
5. Member display




1. Message notification
2. Swipe right to delete
3. Reminder information category



1. Unread status
2. Read status


Weather - Set Time Zone

Navigate to Device Settings - General - Weather Location to ensure that the weather positioning is accurate.



Introduction to Main Functional Pages on Mobile App


Smart Creation, Star Assignment, Reward Creation, Catering Plans: Smart Recipe Creation, Synchronized Import, Member Management, Photo Upload Synchronized Import:



Star Assignment

Create rewards and set rules together.

When you have collected enough stars, you can redeem our pre-agreed rewards with them! Rewards can be items or a special experience. Rewards are created by parents on the mobile app, and children can view their rewards and progress on the device.



Wi-Fi

Icon  to view the WiFi status,  means that the WiFi signal is strong,  means no WiFi, and icon  to view the server status,  means connecting to the server,  means disconnecting the server.

Factory Reset

Deletes all data from your frame. This will permanently delete all your photos/videos, contacts, and settings.