


# User Manual for Noise Canceling In-Ear Mono Bluetooth Headset F910



## Specifications

- Bluetooth version: 5.0
- Transmission distance: 10m
- Battery capacity: about 175mAh
- Standby time: about 250 hours
- Talk time: about 16 hours
- Charging voltage: DC 5V
- Charge Time: 1.2 Hours
- Sound Channel: Mono
- Size: 7 x 4 x 0,9cm



1. Volume Down / Next Track
2. Volume Up / Previous Track
3. Multifunction button
4. USB charging interface
5. Indicator light

## **Headset pairing**

Press and hold the multifunction button for about 2 seconds and the indicator light will flash red and blue. That means that the headset entered into the pairing mode. Turn the Bluetooth on your smartphone and search for the F910 headset, click on it and it will connect automatically.

To disconnect the headset from your phone, you can do it via Bluetooth on your phone or if you move the headset to a distance over 10m from your phone.

## **Headset charging**

The headset has a built-in rechargeable battery. Before you use the headset for the first time, it is recommended to fully charge it. When charging, the indicator will light red and when the battery is full it will light blue.

Please note that the charging voltage should not be higher than 5V.

## **The Bluetooth headset commands**

To power on the headset press and hold the multifunction button for about 2 seconds until the blue light flashes 3 times.

To power off the headset press and hold the multifunction button for about 3 seconds until the red light flashes 3 times.

To answer or end a call, click the multifunction button once.

To play or pause a song, click the multifunction button once.

To reject the incoming call, press and hold the multifunction button for about 2 seconds.

To redial, double-click the multifunction button.

For the voice dialing, long-press the multifunction button for about 2 seconds and start voice dialing.

For the previous song long-press the volume up button for about 2 seconds.

For the next song, long-press the volume down button for about 2 seconds.

For prompt tone switch, tap the multifunction button 3 times.