

User Manual for Front & Rear Car Camera Kit with G-sensor - 1080p/720p



Specifications

- Display size: 4"
- Front camera resolution: 1920x1080
- Front camera field of view: 170 degrees
- Rear camera resolution: 1280x720
- Rear camera field of view: 130 degrees
- Rear camera cable length: 6.5m
- Power cable length: 3.5m
- Video format: MOV
- Photo format: JPEG
- Supported storage: MicroSD up to 32GB (NOT included)
- Battery capacity: 300mAh



1. Back clip fixation hook
2. USB data port
3. Rear pull camera interface
4. Mode selection
5. Up button
6. Ok/Power button
7. Down button
8. LCD screen
9. MicroSD card slot
10. Reset
11. Lens
12. Speaker

Operating instructions

Long-press the power button and the blue light will indicate that the camera is powered on. To power off the camera, long press the power button again and the blue indicator light will go off. If the battery is low, the camera will automatically shut down.

Short-press the mode button to switch to the recording mode. The upper left corner of the display will show the camera icon. Press the ok button to start the recording and the red dot near the camera icon will start flashing red.

Short-press the mode button to switch to the photo mode. The upper left corner of the display will show the camera icon. Press the ok button and the screen will flash once indicating that the photo is taken.

Short-press the mode button to switch to the playback mode. The upper left corner of the display will show the playback icon. Press the ok button to select the file you want to playback.

Settings

Press the mode button and enter the video settings mode. This time, the video icon will be with a yellow background. Short-press the mode button again to exit the video settings.

For the time settings, open the time settings and short-press the ok button to enter. You can set year, month, day, time, and after you're done press the ok button to confirm the change.

Battery charging

While the battery is charging, the red indicator is on, showing the charging status. The charging time is about 180 minutes, and the red charging indicator will automatically go off when the charging is completed.

You can charge the camera using a power adapter or PC via a USB cable.