


User Manual for Bluetooth FM Transmitter / Fast Car Charger BT22



Specifications

- Bluetooth version: 5.0
- Operating distance: up to 3m
- Input voltage: DC 12-24V
- Music format: MP3, MAV, APE, FLAC
- Frequency range: 87.5-108MHz
- USB output: DC 5V/2.4A
- QC3.0 output: DC 3.6-6.5V/3A, 6.5-9V/2A, 9-12V/1.5A
- Dimensions: 83,6 x 48,5 x 45,6mm
- Material: ABS



- | | |
|------------------------------|--------------------------|
| 1. Microphone | 6. Next song/Frequency + |
| 2. LED display | 7. Bass Booster |
| 3. USB reader/2.4A charger | 8. Light switch button |
| 4. QC 3.0 charging port | 9. Volume/Frequency/Call |
| 5. Previous song/Frequency - | 10. MicroSD card slot |

Using the FM Transmitter function

Plug the FM transmitter into your vehicle's cigarette lighter or power port. Tune your radio to an unused FM frequency, then match the same frequency of this unit. Insert the USB disk containing MP3 files into the left USB slot. It will play and transmit the file automatically.

Using Bluetooth function

If using Bluetooth for the first time, you need to pair your mobile phone with this unit. Activate your mobile phone's Bluetooth, then search new device. When the phone detects this unit (named "BT22"), please pair and connect by using the original password "0000" (if needed). In the music-playing mode, when there is an incoming call, this unit will automatically switch to telephone mode.

For Bluetooth calls press the Call button to answer the incoming call. Press and hold to reject the call. During a call, press the Call button to hang up. Press the Call button twice to dial the last number automatically. During a call, press and hold the Call button to switch to a private conversation. When making a call, you can only dial the phone number on your mobile phone, but once the call is connected, you can use the hands-free function.

Bass Music

When listening to music, press the Bass booster button to enjoy the bass audio music. Press again to get back the original audio.

Press and hold the Bass booster button to turn off the FM transmission, LED Display, and LED lights (only the charging function is reserved).

RGB light

Press the light switch button to change different lighting styles. The sequence is shown below:

Red -> Green -> Blue -> White -> Dancing (only while music playing mode - Micro SD/BT/USB-Disk) -> Off

Voice Assistant

Press and hold the light switch button to enter Siri/Google voice assistant.