

Psooo PS-618 30000mAh Solar Power Bank with Hand-Crank





1. Power button
2. Hand crank power handle
3. Micro output cable
4. Lightning output cable
5. Micro output cable
6. LED strong light
7. Solar panels
8. Hand crank charging indicator
9. Solar charging indicator
10. Power indicator
11. USB output port 2
12. Micro input port
13. Type-C input/output port
14. USB output port 1

Technical specification

Type-C Input/Output - 5V/2.4A

Micro Input - 5V/2A

USB Output - DC 5V/2.1A

Size - 170x80x46mm

Temperature range - -20C -40C

Hand cranking power storage

Hand cranking charging clockwise rotation or counterclockwise rotation can give rechargeable power storage.

LED flashlight function instruction

- A. In standby mode, double-click the LED flashlight switch continuously to enter bright mode.
- B. Press the button again to enter SOS mode.
- C. Press the button again to enter burst flash mode.
- D. Finally, double click the switch to turn off the LED flashlight.

With detachable charging cable

- A. Detachable charging cable, compatible with Micro/Type-C interface, to meet a variety of charging needs.
- B. Built-in hidden data cable, can be directly charged digital devices, can also be separated from the direct combination of charging head for device charging.

Instruction

1. Please use the USB cable and charger that matches your phone or other digital products.
2. To ensure stability, please use the standard charger.
3. This product uses Micro and Type-C input ports to charge itself and uses the USB output port to charge the devices that are connected to the product.
4. Electric energy will be consumed during charging/discharging. Slight heating is normal.
5. Please store the product in a cool and dry place. If it is not to be used in a long time, please fully charge the power bank once every six months.
6. One Micro USB cable is attached inside.