

4K Dual Lens Dash Cam with GPS Tracking




Introduction to main functions of mobile app

1. Download app

App loading can be performed in two ways:

1. Go to the app store to download

For IOS system, you can search "Viidure" in the app store to download:



2. Scan the QR code for IOS and Android systems, which can be downloaded by scanning the QR code "Viidure"APP. The steps are as follows:

- Open the software with "scan" function to scan
- Select the corresponding system of the mobile phone and click to download



2. Registered account

- Enter the "Viidure" app for account registration
- Fill in the corresponding information as required, obtain the verification code and fill in it. Click registration to complete the operation

3. Connecting the camera

- Enter the mobile phone wifi list (as shown in the figure below), click "FHCam-*****" to enter the recorder device name, enter the password "12345678", and the mobile phone is successfully connected to the recorder;




- Log in to the downloaded app,"Viidure" enters the main interface, click the camera icon above "FHCam-*****" to enter the recorder screen;




4. Parameter setting

Set the parameters of the dash cam, such as modifying the WiFi password, recording or not, and displaying the watermark time, Video cycle time, collision sensitivity, video resolution, etc.



5. Video review and download



Key function description

Please note that this product must be connected to a power source to turn on and function.



When the device is powered on and operating normally, press and hold the power button for 3 seconds to turn it off.

When the device is powered on but turned off, press and hold the power button for 3 seconds to turn it on.

Please note the insertion direction when inserting the TF card. Please use a TF card with a capacity ranging from 8G to 128G.

For the rear lens interface, ensure that the rear lens plug is fully inserted.


Insert the power cord into the interface.

Troubleshooting:

Under normal operating conditions, if the products have problems, please refer to the solution:

1. Could not take photos, video Check TF card whether there is enough space, whether locked.
2. When recording, it will automatically stop Because of the huge high-definition video data, use SDHC compatible high-speed TF card, high-speed TF card will be C10 identity.
3. Replay pictures and videos, the "File" prompt An error occurred when TF card memory data, resulting in incomplete files, using the Car DVR "Format" function, reformat the card.

4. The image is foggy
 - Please check the lens for dirt and finger prints. Before shooting, wipe the lens with lens paper.
5. Open the network access permission for the first time, and open the local photo album.
6. If the mobile phone cannot be connected to the product, first of all, check whether the mobile phone is connected to other WiFi hotspots. The app can only be connected to the recorder when the WiFi in the mobile phone settings is connected to the recorder (for example, at home, it is found that the recorder cannot be connected, so it is necessary to check whether the WiFi signal in the mobile phone settings is connected to the WiFi in the home).



7. The real-time picture of the mobile phone is stuck, which is generally related to the WiFi signal. For example, when the mobile phone is too far away from the recorder, the WiFi signal is weak, and the real-time picture of the mobile phone will get stuck. In addition, if there are too many WiFi signals around the recorder, it will also interfere with the recorder and cause the real-time picture to jam.
8. The preview speed in the album is very slow. It may be that there are too many video files in the TF card, resulting in the timeout of obtaining file information. Consumers are advised to format TF cards regularly.
9. Record appearance and many clients connect to it. But only one mobile phone can be used to link at the same time. If it is found that the mobile phone cannot be connected to the recorder, it should be ruled out whether the recorder is connected to other mobile phones.
10. Use the computer to play video recordings: The product uses H.264 compression format. The file type is mov or MP4 format. Many Microsoft Windows computers' built-in playback software bodies (such as Windows Media Player) do not support H.264 encoding format. It may not be able to play, or the playing of the movie is not smooth, the frame is fixed or broken, or the video and audio are not synchronized. It is recommended to download other professional playing software (such as potplayer, etc.).