


**SMILE KIDS ALARM CLOCK WITH COLORFUL NIGHT LIGHT**



# Product overview



- 1. Child safety lock
- 2. Up/down
- 3. Setting function
- 4. Nap time setting
- 5. Night light
- 6. Sound
- 7. Battery CR2032
- 8. Sleep/wake up time setting
- 9. Alarm setting
- 10. Time setting
- 11. Snooze

Remove the insulation from the button cell battery before turning the device on.

## Functions

1. Lock: short press the Lock button to lock all the functions. Long press the button to unlock the clock.
2. Set: press the Set button to enter the setting mode. The LCD screen will display "SET". Press the corresponding button to enter the desired function. For example press the Time button to set time then press Set again to confirm and exit.
3. Time: In regular mode press the Time button to choose between four brightness levels.  
In setting mode press the Time button to set the right hour using the +/-, then press the button again to set the right minute. Press the button again to choose between a 12 or 24 hour format.
4. Alarm: In regular mode press the Alarm button to activate/deactivate the alarm function. When the alarm is deactivated the alarm icon will disappear. In regular mode long press the Alarm button to change 12/24 hours format. In setting mode press the Alarm button to set the alarm hour, then press again to set the minute using the +/- . Press the button again to choose between five alarm ringtones.
5. Wake up/sleep: in regular mode short press this button to turn on/off sleep trainer. Long press the button to switch between °C/°F.  
Under setting mode press the Wake up/sleep button to set the wake up/sleep time. 30 minutes before bedtime the blue light will turn on. When it's time for bed, the clock eyes will close, the moon icon will appear, and the screen light will dim. 30 minutes before wake up time, the light will turn yellow. When it is time to wake up the eyes will be open, the sun icon will appear, the green light will be turned on for one hour, and the screen brightness will turn to last set brightness.
6. Sound: in regular mode press the Sound button to turn the music on or off. In setting mode press the button and use +/- to choose between eight different sounds. Press the Sound button for the second time to select the duration of the chosen sound (10min, 20min, 30min, 45min, 1h, 1h30min, always on).
7. Light: In normal mode press the Light button to turn on/off the night light. Under setting mode, press the Light button to display "10", then press +/- to set how long the night light will stay on (10m,20m, 45m, 1hr,1hr30m, always ON). 3.Press the Snooze button to adjust the brightness of the light. The night light has 3 levels of light brightness adjustment.
8. Nap: in regular mode press this button to turn on/off the nap timer. In setting mode press the button and use +/- to set nap time duration. Press the button again and use +/- to choose the reminder mode. (LI stands for light, AL stands for alarm)

9. Snooze: in nap mode press the Snooze button to view the remaining nap time.  
When the nap mode is off, press the Snooze button to view the alarm time.  
When the alarm/nap time arrives press the Snooze button to activate the snooze feature for 10 minutes, or hold the button for 2s to deactivate the feature.