# Super Loud Alarm Clock for Heavy Sleepers with 7-Color Night Light - Black

1. Alarm 1
2. Alarm 2
3. Daylight saving time
4. AM/PM indicator
5. Backup-battery compartment 3xAAA batteries (Not included)
6. USB charger DC 5V/1A
7. Power input
8. Display color charging
9. Screen brightness control
10. Volume adjust & up
11. DST & down
12. Time set & 12H/24H
13. Alarm 1
14. Alarm 2
15. Nightlight color changing

① & ② Alarm 1 & 2 - Press the button to enter the alarm setting, and the current alarm time will be displayed.
Press the alarm button again to toggle it on or off.
Press and hold the button for 3s to set the alarm time.

③ Nightlight color changing - Press the button to select the color of the nightlight.
There are a total of 7 nightlight colors.
Press and hold for 3s to turn off the light.
The button can also be used as a "snooze" button.

Package includes

- Digital alarm clock
- User manual
- USB cable
- 5V/1A power adapter

Note: The digital clock needs to be plugged in for operation. The batteries are only used to save settings when the clock is powered off.

Product features

Input voltage: AC 100V-240V, 50/60Hz
Output voltage: DC 5V /500MA-2100MA

Time setting

1. Hold ⚙ for about 4s to enter time setting mode.

2. Press + or - to set the "Hour" value". Press ⚙ to confirm.

3. Press + or - to set "Minute" value". Press ⚙ to confirm and finish time setting.

12/24H Switch

1. Press ⚙ to select "24-Hour" mode or "12-Hour" mode.

If "12-Hour" mode is selected, an "AP/PM" indicator will be displayed.

Alarm 1 setting

(Alarm 2 is the same as Alarm 1)

1. Press the button to enter the alarm setting, and the current alarm time will be displayed.

When Alarm 1 is enabled, an alarm icon will be displayed.

2. Press the alarm button again to toggle it on or off.

3. Press and hold the "Alarm 1" button for 3s to set the alarm time.

4. Press + or - to set the "Hour" value. Press "Alarm 1" to confirm.

5. Press + or - to set the "Minute" value. Press "Alarm 1" to confirm and finish "Alarm 1" time setting.

Alarm volume

Press + to select alarm volume. There are 5 levels of volume (u1--u5).

After selecting an appropriate volume, wait for about 2s until the clock will confirm your choice automatically.

Activating snooze when alarm goes off

When Alarm 1 (Alarm 2) is sounding, press the SNOOZE button on the top, the alarm will suspend and go off again after five minutes.

Stopping alarm when it goes off

When Alarm 1/2 is sounding, the related ① ② indicator flashes. Press any buttons (except the SNOOZE button on the top) to stop and reset the alarm to go off the next day.

RGB color changing display

There are 12 different colors of lighting modes.

Press the "Display" button to change the display color.

Screen adjusting brightness

In the normal display state, press to adjust the brightness.

Nightlight color changing

Press the button to select the color of the nightlight. There are a total of 7 nightlight colors. Press and hold for 3s to turn off.

Daylight saving time

In the normal display state, press - to toggle DST mode.

When DST is in effect, the DST icon will be displayed on the screen.