


User Manual for 3-in-1 Wireless Charging Station W55



Specifications

- Interface: USB Type-C
- Input: 5V/2A, 9V/2A
- Output: 15W (phone), 3W (AirPods)
- Charging distance: <8mm



1. Phone charging area
2. Watch charging area
3. Silicone pad
4. Earphone charging area
5. LED indicator
6. Type-C input
7. Snap switch
8. Silicone pad


How to use

Connect the wireless charger to the adapter using the Type-C cable and power it on. Put the phone in the charging area and the green indicator LED will light up indicating that the phone started to charge. If it's not charging normally, please adjust the position of the device until it shows normal charging or the green LED light up. Do the same for the wireless charging headphones.

To charge the Apple Watch, you'll have to put your Apple Watch charger to the watch charging area first and then put the watch on it to charge.

Please note that it is recommended to use adapters and fast charging cables above 9V/2A in order to charge all devices at the same time. If you use an adapter less than 5V/2A, it will not be able to charge all devices at the same time.

If the LED indicator flashes with blue light, it means that the wireless charging station detected a foreign object or the input voltage is too high. Please remove the foreign object or connect the correct power adapter so that the wireless charging station can charge devices normally.



To place the Apple Watch charger into the charging station, first of all, open the bottom cover (1). Place the charger in its position (5) through the charging hole (4) and then place the cable depending on its length. If the cable is 100cm long, go to slot 1, if it's 80cm long go to slot 2 and if it's 30cm long then go to slot 5. Once you do that, plug the cable into the USB port for Watch charging (2). Put back the bottom cover, connect the wireless charging stand to the power supply and you're all set.