

User Manual for Portable Hand Crank Solar Radio with LED Flashlight



Specifications:

- Radio frequency: AM/FM/WB
- Speaker: 40mm, 1W
- Power source: solar panel/dynamo/internal battery
- Battery capacity: 600mAh
- Battery type: 18650
- Power bank output: USB-A, 5V
- Charging input: MicroUSB
- Dimensions: 129mm x 60mm x 50mm

Product overview:

1. Display
2. Tuner dial
3. Radio band switch
4. Radio on/off & volume
5. Ports
6. Antenna
7. Solar panel
8. Hand crank
9. Flashlight on/off



Radio instruction:

- Turn the volume dial clockwise to turn the radio on and control the volume.
- Select AM, FM, or WB radio bands. The green tune indicator light will turn on when the station selected is fully engaged.

Flashlight instruction:

- 3 levels of lighting: strong, middle, and weak.
- Press the button to turn it on. Press the button again to change the lighting level.
- Press the button three times to turn off the flashlight.
- Long press the flashlight button to activate the SOS function, long press to turn it off.

Charging methods:

1. Solar
2. Hand crank
3. USB port

Solar charging:

- Place it in average sunlight for approximately 10-12 hours, the red power indicator illuminates when charging.

Hand crank charging:

- Lift the hand crank and rotate it clockwise or counterclockwise for 3-5 minutes to activate the internal battery. The red power indicator illuminates when cranking. For an additional use, rotate it for 1 min to provide 15-20 min of continuous radio usage.

USB charging:

- Insert one end of the charging cord into the microUSB port and the other end into the computer USB port. The red power indicator illuminates when the battery is charging.